

CIVIA LOWRY FRAMESHEET

Civia offers stylish, comfortable, affordable bikes that allow people to discover the joy just around the corner. We believe that riding a bike helps you see the world in a new way, that some of life's best things are found right outside your front door, and that life is more than getting from one place to another. Thanks for buying a Civia.

⚠WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

Additional Product and Safety instructions can be found at www.civiacycles.com/safety

RETAILER: This framesheet MUST BE provided to the end user.

INTENDED USE



CONDITION 1 CITY TREKKING

Our bikes are designed for riding on a paved surface where the tires are always on the ground.

GEOMETRY CHART

Measurements in mm unless noted

	XS	SM	MD	LG	XL
Approx. Rider Height	5'0"-5'4"	5'3"-5'7"	5'6"-5'10"	5'9"-6'0"	5'11"-6'3"
Effective Toptube	554	574	584	595	605
Seat Tube Length (Step Over)	n/a	510	530	540	560
Seat Tube Length (Step Thru)	470	480	530	540	n/a
Headtube Angle	69°	69°	70°	70°	70°
Seat Tube Angle	70°	70°	70°	70°	70°
Wheelbase	995	1015	1047	1058	1068
Stack	518	518	567	567	567
Reach	366	386	376	389	399
Standover (Step Over only)	n/a	749	792	799	811
Wheel Size (ETRTO)	26" (559mm)	26" (559mm)	700c (622mm)	700c (622mm)	700c (622mm)

• Standover is measured vertically from the top of the toptube, 200mm forward of seatpost center

GENERAL SPECIFICATIONS & COMPATIBILITY

Frame Material	Aluminum
Fork Material	Steel
Wheel/Tire Max	XS/SM: 26 x 1.75" max; MD-XL: 700c x 45mm max
Wheel/Tire Alternates	XS/SM: 26 x 1.5" w/fenders; MD-XL: 700c x 38mm w/fenders
Fork Axle to Crown	XS/SM: 378mm; MD-XL: 405mm
Fork Offset	45mm
Headset	1" threaded
Seatpost	27.2 x 350mm length, 0mm offset
Seat Collar	31.8mm
Cable Routing	Standard external
Front Derailleur	None
Bottom Bracket	68 x 113mm English, 1.37 x 24mm threading
Crankset (Max Ring)	44t ring
Brakes	Caliper only
Front Hub/Axle	100mm OLD/10mm, threaded
Rear Hub	7-speed: 134; 1-speed: 121mm OLD
Rear Axle Size	10mm, threaded
Derailleur Hanger	Not serviceable, slotted
Rear Rack Mounts	Yes (seatstay & dropout)
Front Rack Mounts	None
Fender Mounts	Yes, center mount (brake post) & dropout
Bottle Mounts Per Bike	1 set on downtube, 64mm spacing, M5
Quill Stem Extension	XS/SM: 80mm; MD-XL: 100mm
Quill Stem Angle	-17° rise
Headset Spacers	None
Headset Upper Stack	13mm
Bar Width	XS/SM: 570mm; MD-XL: 595mm
Bar Rise	66mm
Bar Sweep	43°
Crank Arm Length	XS/SM: 165mm; MD-XL: 170mm

CIVIA

CARE AND MAINTENANCE

Keep your frame clean. Dirt and road grime lead to oxidation and fading of the finish, and they make it hard to do a thorough inspection. Dirt will accelerate any abrasion of the paint that comes from rubbing, such as places where the cable housing touches the frame. In extreme cases, this type of abrasion could remove frame material.

When your bicycle is not being ridden, store it where it will be protected from rain, snow, sun, etc. Rain or snow may cause the metal on your frame to corrode.

If your bicycle was exposed to moisture during a ride, thoroughly dry the bicycle before storing it. If water got inside the frame, tilt the bicycle to drain the water. If necessary, remove the seatpost and turn the bicycle upside down. This is especially critical if there is a large amount of water inside. If water freezes inside your frame, the expansion of the ice can crack and rupture the structure.

Before storing your bicycle for an extended period of time, clean and lubricate the frame with a frame wax, polish, or protectant. Do not store the bicycle near electric motors, as ozone from motors destroys paint. Before riding the bicycle again, follow the pre-ride checklist to be certain it is in good working order.

PRE-RIDE CHECKLIST AND INSPECTION

Before every ride carefully inspect your frame and fork for damage, cracks or any other signs of fatigue. If any frame part or fork shows signs of damage or fatigue, consult your dealer immediately or replace the frame or fork before riding the bicycle. Regularly inspect all components for any damage or extreme wear and replace upon detection. Please also check and inspect brake function as well as proper wheel mounting before each ride. For more information, please refer to the Civia Owner's Manual received with your bike or at www.CiviaCycles.com/safety/.

In the event of a crash or impact, carefully inspect handlebars, fork, stem, seatpost, wheels and the frame for any visible damage. As with any component under varying degrees of stress there is a fatigue life that is proportional to the type of use and abuse applied to the part. Always inspect your components before a ride. If you have doubts about the integrity and condition of any part, replace it. Consult your dealer if you are unsure about the condition of your Civia frame or fork or any part of your bicycle.

▲WARNING: An improperly modified frame, fork, or component can cause you to lose control and fall. NEVER MODIFY YOUR FRAMESET.

▲WARNING: Attaching incompatible clamping devices to a fork can lead to fork breakage, causing a loss of control. If you are not sure if a device is compatible, consult your dealer.

Get a pen and write down the serial number of your Civia immediately. The number is stamped into the bottom of the bottom bracket shell. Having this number is imperative if your bike ever gets stolen or if you ever have questions about your frame.

SERIAL NUMBER: _____

CIVIA LIMITED WARRANTY

All Civia products are warranted against manufacturing defects in materials and workmanship from the date of retail purchase of the product, subject to the limitations detailed below. Every Civia frame, fork and component has a useful product life cycle that depends on the construction, material, maintenance, amount and type of use of the product. Save your dated receipt for proof of purchase.

Three Years

- Aluminum frames

Two Years

- Steel bicycle forks

This warranty applies to only Civia branded product. Any other original part or component shall be covered by the stated warranty of the original manufacturer. Any products not specifically included above are hereby omitted.

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the product
- Bent or broken derailleur hangers
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly
- Normal wear and tear

This limited warranty is expressly limited to the repair or replacement of a defective product, at the option of Civia, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the Civia product and is not transferrable. This warranty applies only to Civia products purchased through an authorized dealer or distributor. In no event shall Civia be liable for any loss, inconvenience or damage, whether direct, incidental, consequential, or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to Civia products except as set forth herein. This warranty gives the consumer specific legal rights, and those rights and other rights may vary from place to place. This warranty does not affect your statutory rights.

WARRANTY REGISTRATION

Proof of purchase is required before a warranty claim is processed. Civia strongly encourages warranty registration at civiacycles.com. Failure to register will not affect consumer rights under the limited warranty stated above, so long as the consumer can show in a reasonable manner proof of original ownership and the date the Civia product was purchased.

If you have questions, please contact info@civiacycles.com.

Civia Cycles
6400 W. 105th Street
Bloomington, MN 55438
(866) 892-9110

CIVIA